


W. S. WEST FINE CLOTHIERS/RIPLEY SHIRTS

MEN'S JACKET MEASUREMENTS

JACKET MEASUREMENTS

POINT TO POINT (SHOULDER)	
CHEST	
HALF CHEST FRONT	
OVERARM	
BICEP	
STOMACH	
HALF STOMACH FRONT	
WAIST	
HALF BACK	
SEAT	
HALF SEAT BACK (BUTT)	
SLEEVE LENGTH: RIGHT:	
LEFT:	
SLEEVE INSEAM: RIGHT:	
LEFT:	
JACKET LENGTH	



CHEST (HALF CHEST)

Remove the customer's jacket. Standing behind the customer, place the tape over the fullest part of his chest, under the armholes, and around to the back covering his blades. The tape should be snug but not tight (one finger under the tape). This measurement is indicated for "Half Chest".

STOMACH (HALF STOMACH)

Take this measure on the shirt on the fullest part of the stomach. Take it snug but not tight (one finger under tape).

WAIST (HALF WAIST)


This refers to trousers waist. Ask the customer to open the top of his trousers and to hold up his trousers. Place the tape around the smallest part of his waist.

SEAT (HALF SEAT)

The trousers pockets must be empty. With the customer's feet together, measure fullest part of the seat, also with one finger under the tape. We will give the customer the extra room he needs to be comfortable.

VEST MEASUREMENTS

FRONT OPENING	
FRONT LENGTH	
BACK LENGTH	



JACKET TOTAL LENGTH


From collar over the middle back seam to the length position that the customer requires.

HALF BACK

Measurement across the back from hindarm seam on the sleeve to the back middle seam.

SLEEVE LENGTH

From the sleeve head on the shoulders to the length that the customer requires.



LENGTH TO OPENING

Measure from the nape of the neck to the opening position as required.

FULL LENGTH

Start from the nape of the neck to the full length as required.

BACK LENGTH

From the center back neck to 2 cms. below the trouser waistband.

JACKET AND/OR VEST REMARKS:
